

Be sure to read this instruction manual before using this product. Keep this manual available for reference when needed.

# MES-CK08-080-11EN-0 PREPARED: (2020-08-11) (Version3)

# Instruction for Use

## Trade Name: Adjustable Body Support

#### Warning

When using operating table accessories, always pay close attention to the patient. Patients left in the same posture for an extended period of time are at risk for developing nerve paralysis and/or bedsores.

#### **Contraindication/Prohibition**

This product is only validated for use with Mizuho operating tables.

#### Symbol mark for labeling



# Specifications

1. Shape



Code No.	Product Description	Components
08-080-11	Adjustable body support with clamp	12345678
08-080-11-NC	Adjustable body support (NC)	345678
08-110-01	Clamp for Round Bar *1	00
08-117-09	Clamp for Round Bar (R1) *2	09
08-117-11	Clamp for Round Bar (R2) *3	20

\*1, \*2 and \*3: The size of mountable side rail is different.

- 2. Weights
  - Main Body: 2.5kg Clamp for round bar: 0.9kg
- 3. Material
  - 190 Rail clamp: Stainless cast steel
  - $\ensuremath{@}$  Fixing handle: Stainless steel rod
  - ③ Arm: Stainless steel rod
  - ④ Pad: Urethane foam
  - Stopper lever: Stainless steel rod
  - © Stopper collar: Stainless steel rod
  - ⑦ Adjustable screw: Stainless steel rod
  - Nut: Stainless steel rod

Note: The number corresponds to those used in 1. Shape.



Arm<sup>3</sup> has a piston(c) which is contacting with the ball part of the Pad<sup>®</sup>. Also, it has a plunger(a) and a spring(b) which re contacting with the Stopper lever<sup>®</sup>. Hydraulically operated piston(c) (and the spring) inside the Arm<sup>®</sup> moves up and down to make the Pad<sup>®</sup> and Stopper lever<sup>®</sup> move.

#### 4-1. How to fix

Pushing the Stopper levers downward, a spherically shaped part at the bottom of the Stopper levers will push back the plunger(a) to the other side. This movement makes the piston(c) to hydraulically moves up to the ball part of the Pad@.

Then the Pad<sup>®</sup> will be hydraulically fixed at the Arm<sup>®</sup>.

### 4-2. How to unfix

Pushing the Stopper lever<sup>®</sup> upward, a spherically shaped part at the bottom of the Stopper lever<sup>®</sup> will apply the tension to the spring(b) and the plunger(a) will move back to the Stopper lever<sup>®</sup> side. This movement makes the hydraulic pressure applied to piston(c) to be relieved and the Pad<sup>®</sup> will be unfixed.

Thus  $\ensuremath{\mathsf{Pad}}\ensuremath{\textcircled{\sc 0}}$  and  $\ensuremath{\mathsf{Arm}}\ensuremath{\textcircled{\sc 0}}$  will be free.

#### Intended purpose

This is an accessory to an operating table.

This is a tool for supporting a patient lying in the lateral recumbent position for a thoracotomy or similar procedure. Move the Pad@ and Arm@ to a position (height and angle) appropriate for the patient's posture.

#### Intended user

This product is to be used by health care professionals, including but not limited to surgeons, nurses and biomedical technicians.

#### Instructions for use



© Fixing handle
© Stopper collar
③ Arm
⑦ Adjustable screw
④ Pad
⑧ Nut

#### 1. Instructions for use

1.1 Attach the Rail clamp<sup>①</sup> to the side rail of an operating table.

(B)

 $\bigcirc$ 

Ē

D

- 1.2 Move the Rail clamp<sup>①</sup> to a position appropriate for the patient's posture.
- 1.3 Turn the Fixing handle<sup>®</sup> clockwise to secure the Rail clamp<sup>®</sup>.
- 1.4 Push the Stopper lever downward and pull the Stopper collar toward you. Lock on the Pad and Arm will be released. (Figure B)
- Move the Pad® and Arm®to a position (height and angle) appropriate for the patient's posture.

After the adjustment, push the Stopper lever $\$  downward. The Pad $\$  and Arm $\$  will be locked. (Figure C)

2. How to adjust

Use the Adjustable screw<sup>®</sup> to properly adjust (tighten or loosen) the Pad<sup>®</sup> and Arm<sup>®</sup>.

- 2.1 Make sure that the Pad<sup>®</sup> and Arm<sup>®</sup> are locked.
- 2.2 Unscrew the Adjustable screw<sup>®</sup> with the tool. (Figure D) Turn the Nut<sup>®</sup> clockwise (two turns) while holding the Adjustable screw<sup>®</sup>.

Use another tool to hold the Adjustable screw  $\ensuremath{\textcircled{O}}$  so that the screw will not rotate.

- 2.3 Push the Stopper collar® downward towards the Stopper lever® and pull it toward you. Lock on the Pad@ and Arm® will be released. (Figure B)
- Rotate the Adjustable screw to properly adjust (tighten or loosen) the Pad® and Arm<sup>3</sup>. (Figure E)
  - Turn the Adjustable screw@ clockwise (one quarter) if the
  - Pad<sup>®</sup> and the Arm<sup>®</sup> need to be tightened.Turn the Adjustable screw<sup>®</sup> counterclockwise (one quarter) if
  - the Pad® and the Arm® need to be loosened.
- 2.5 Repeat the Step 2 to 4 until the Pad $\circledast$  and the Arm $\circledast$  are properly fixed.
- 2.6 Pull the Stopper lever<sup>®</sup> upward and push the Stopper collar<sup>®</sup> downward. Make sure that the Pad<sup>®</sup> and Arm<sup>®</sup> are locked. (Figure C)
- 2.7 After the adjustment, secure the Adjustable screw with the tool. While holding the Adjustable screw with the tool, turn the Nut counterclockwise to tighten until it reaches the Adjustable screw. (Figure D)

### Warning/Caution

## 1. Warning

Ensure all fixing handles are tight. Loose condition can cause the product to come off or move, which may result in a patient injury.

- 2. Important caution
  - 2-1. When working with an operating table, take care not to allow this product to make contact or interfere with the table top or with other tools and appliances used in combination with this product. Otherwise the product could break.
  - 2-2. Do not use for an operating table with a radiographic top attached or a built-in radiographic top because the stopper interferes with this product.
  - 2-3. For hygiene, be sure to use sterilized drapes on the areas on this product where the patient comes into contact with it.

#### Storage/Life

- 1. Do not store the device in high temperatures or in areas with high humidity where the temperature has drastic variations.
- Service life of this product: 7 years (subject to the specified maintenance and inspection and is stored properly)

#### Maintenance/Inspection

- <By the user>
- 1. Inspection before and after use

Check that this product is not damaged or broken before and after each use.

2. Cleaning and disinfection

Wipe off blood, chemicals, contaminants, and other stains with water, and clean the device with gauze or other material moistened with alcohol to disinfect.

3. In case of a malfunction

When this product is broken, clearly label the device as "Broken", "Do not use", "Need repair", etc., and contact your local dealer or Mizuho.

<By agents>

Maintenance and inspection can only be carried out by certified agents of Mizuho.

### Packing

1 piece per pack

#### Warranty

MIZUHO Corporation will repair defective parts of this product without charge for one year from the date of delivery/installment except for cases of damage caused by a third party's repair, act of nature, improper use or intentional damage. All other warranty terms and conditions are subject to regulations of MIZUHO Corporation.

#### Disposal

ര

0

This device must be disposed of in accordance with local regulations. Please contact your local distributor for proper disposal.

#### Notice

Any serious incident that has occurred in relation to the device should be reported to the manufacturer and the competent authority in which the user and/or patient is established.

#### Manufacturer



MIZUHO Corporation 3-30-13 Hongo, Bunkyo-ku, Tokyo 113-0033, Japan http://www.mizuho.co.jp

# European authorized representative



Emergo Europe B.V. Prinsessegracht 20, 2514 AP, The Hague The Netherlands